Beer Foam as a Multiphase System

Růžička, Marek
2015

Beer foam as a multiphase system

Marek Růžička

Department of Multiphase Reactors
Institute of Chemical Process Fundamentals
Czech Academy of Sciences
www.icpf.cas.cz

Contents

==========

Part 1. Multi-Phase systems

==========

Basic orientation

I. Definition of Multi-Phase

1. Intuitive

"Multiphase flow is when water flows together
with bubbles, drops, and particles."

2. Exact

Phase = macroscopically distinguishable material substance
immiscible with others.

macro - bulk system, continuum,
immiscible - separation, no dissolution.

a) Continuous phase - fluid phase carrying 'particles' (fluid = gas, liquid),
b) Discrete phase(s) - dispersed 'particles' (bubbles, drops, solids).

Examples - phases

Three states of matter: gas, liquid, solid
(NOT water + salt: microscopic, true chemical solution)

Two **liquids**: water + oil (NOT water + ethanol, miscible)

Two **gases**: NO (miscible, no interface tension!)

Two **solids**: peas + ashes /hrách + popel/

Ms. Popelka /Cinderella

A multiphase researcher in dry granular media,
system gas-solid-solid, namely phase-separation aspects

II. Multi-Phase abounds

1. Natural systems

Two main continuous phases: air & water (ev. two more fire + ether)

Air (gas)

- aerosols (g-l-s),
- rain (g-l),
- snow (g-s),
- volcano (g-s-f) f - fire /plasma state/
- fires (g-f-s)
- soil, sand, rocks, ... (g-s) granular system /dry or wet/
- people, animals, ... (g-s) /particles, bodies dispersed in air/
- solar, galactic, universal, cosmic systems (s-e) e - ether /'dark matter template'/

Water (liquid)

- sea waters (l-s-g):

g - bubbles of CO_2, CH_4 - carbon cycles,
s - sediments, fish, submarines, icebergs, ...
l - drops of oil,

- fresh waters: ... similar ....

2. Man-made (artificial) systems

All technologies:

- to contact phases,
- inter-phase transport processes (mass, momentum, energy),
- reaction phenomena (old / new compounds),
- separation steps (wanted / unwanted substances),
- concentrate / dilute,
- use, consume, waste.

Example

Beer

(un-filtered)

l-g-s double-three phase system

Liquid (golden): water (true solution) + bubbles + yeast ('particles')

Foam (silver): gas (near 100% volume) + liquid films + yeast

"The Golden-Silver One"

Note

Foams = stable bubbles
Liquid film drainage is supressed by surface gradients of surface tension, produced by surface gradients of surfactant concentration (Marangoni effects).

Department of Multiphase Reactors

g-l bubble columns, aerated systems,
bubble formation, rise, coalescence, breakup

g-l-s fermenters, flotation,

s-l sedimentation,

s-g granular matter (powders - many of !),

g-l foams.

Some pictures on bubbles ...

Bubble formation

Single orifice



Two orifices - close spacing



Two orifices - distant spacing

Bubble coalescence

Bubble breakup



Bubble dispersion

Diluted



Dense

Bubble foam

Wet



Dry



==========

Part 2. Gushing experiments: How to begin ?

==========

Didactical guide - not only for students

Desaturation cell - measuring apparatus



- glass cylinder for low pressures of CO_2 gas (3-10 bars),

- liquid sample (beer) for foam production,

- procedure: liquid saturation and desaturation
  (shaking) (cell opening)

- measured data: visual (video) + pressure (transducer),

- results: foam production dynamics, p(t), h(t)

→ → → **max foam height H, mean growth rate R**

1. Parameters describing the system

Experimental cell

- shape,
- dimensions,
- working volume,
- sample volume.

Ambient conditions

- temperature, pressure, humidity, light conditions, contaminants, ...

Solutions

- foaming agent (chemical substance),
- producer and type,
- way of storage,
- concentration (relevant units, grams x moles),
- solution preparation (fresh x stored) and conditioning,
- solution use (single x multiple).

Operation parameters

- saturation pressure,
- sample motion (shaking x sloshing, frequency, amplitude),
- saturation time,
- valve opening time (manual x solenoid valve - PC).

2. Definition of "Reference State" [RS]

Sample volume:	V = 0.5 l,
Ambient conditions:	laboratory,
Foaming agent:	BSA (model substance),
Concentration:	c = 0.5 g/l,
Solution:	fresh, single use,
Saturation pressure:	p_0 = 3 bar,
Saturation time:	T_{AB} = 45 min,
Valve opening:	PC-controlled.

3. Performing experiments

Data acquisition

- pressure signal (sensor - parameters, T-scales, A/D converter),
- video (parameters: resolution, pixel/mm, optical distortion, synchron.),
- precision, sensitivity, errors, reproducibility.

Data treatment

- pressure signals (Volts into Pascals, time series-p, diagrams),
- videos (pixels into mm, time series-h, diagrams),
- errors, statistics, mean values, deviations, function of random variables.

Results

- results: p(t), h(t), H, R,
- range of validity, reliability, robustness.

4. Basic rules for experiments

Start with "Reference State": test its stability and reproducibility.

Never change more than 1 parameter (in words: 'one').

When in problems, resort to "RS" - the only 'fixed point' in Universe.

5. Basic test measurements

Purpose: mapping the neighbourhood of "RS" in parameter space.
"What would happen, if I make a little error in measurements ?"

But not only !

Test the foaming agent BSA: effect of source, storage, ...

Test the solution: single x multiple use.

Test the mode of saturation: frequency + amplitude of shaking, time period.

Test the mode of cell opening: rate of gas release.

Test the effect of saturation pressure.

6. Planning experiments and 'doing science'

Only now

you may carefully plan

your live 'research' measurements :)

Acknowledgements

The financial support by the Ministry of the Czech Republic - MSMT (Project No. LD-13018) is gratefully acknowledged.